

Pioneer

Service Manual



X-SMC3-K

ORDER NO.
RRV4209

Slim AV Micro System

X-SMC3-K

X-SMC3-S

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).


Model	Type	Power Requirement	Serial No.	Remarks
X-SMC3-K	CUXZTSM	AC 100 V to 240 V	&&&#####UC	UC : U.S., Canada
X-SMC3-K	SYXZT8	AC 100 V to 240 V	&&&#####YY	YY : Europe
X-SMC3-S	CUXZTSM	AC 100 V to 240 V	&&&#####UC	UC : U.S., Canada
X-SMC3-S	SYXZT8	AC 100 V to 240 V	&&&#####YY	YY : Europe



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
 ©PIONEER CORPORATION 2011

K-IZV NOV. 2011 Printed in Japan

3.3 PCB LOCATIONS



NOTES: ● Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
 ● The Δ mark found on some component parts indicates the importance of the safety factor of the part.
 Therefore, when replacing, be sure to use parts of identical designation.

LIST OF ASSEMBLIES

Mark	Symbol and Description	X-SMC3-K /CUXZTSM	X-SMC3-K /SYXZT8	X-SMC3-S /CUXZTSM	X-SMC3-S /SYXZT8
	DISPLAY PCB ASSY	A11602ADP0	A11601ADP0	A11607ADP0	A11603ADP0
	DOCK PCB ASSY	A11602AFF0	A11601AFF0	A11607AFF0	A11603AFF0
	BLUETOOTH PCB ASSY	A11602AFG0	A11601AFG0	A11607AFG0	A11603AFG0
	MAIN PCB ASSY	A11602AF40	A11601AF40	A11607AF40	A11603AF40
	OPERATION PCB ASSY	A11602A270	A11601A270	A11607A270	A11603A270
	TUNER PCB ASSY	A11602A290	A11601A290	A11607A290	A11603A290
	LCD	09EQ12R401	09EQ12R401	09EQ12R401	09EQ12R401
	Network Module	16EB00003A	16EB00003A	16EB00003A	16EB00003A
	Speaker	SWP1033	SWP1033	SWP1033	SWP1033
	Speaker	66-226PA/XTW-14	66-226PA/XTW-14	66-226PA/XTW-14	66-226PA/XTW-14

X-SMC3-K