


# Pioneer

## Service Manual



PD-30-K

ORDER NO.  
**RRV4333**

Super Audio CD Player

# PD-30-K

## PD-30-S

## PD-10-K

## PD-10-S

## PD-10

**THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).**

| Model            | Type     | Power Requirement | Remarks |
|------------------|----------|-------------------|---------|
| PD-30-K, PD-30-S | PWSYXZT8 | AC 220 V to 230 V |         |
| PD-10-K, PD-10-S | PWSYXZT8 | AC 220 V to 230 V |         |
| PD-10            | FXZT     | AC 110 V          |         |



**PIONEER CORPORATION** 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan  
**PIONEER ELECTRONICS (USA) INC.** P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.  
**PIONEER EUROPE NV** Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium  
**PIONEER ELECTRONICS ASIACENTRE PTE. LTD.** 253 Alexandra Road, #04-01, Singapore 159936  
©PIONEER CORPORATION 2012

K-MZV JULY 2012 Printed in Japan

