


Pioneer

Service Manual



A-30-K

ORDER NO.
RRV4297

INTEGRATED AMPLIFIER

A-30-K

A-30-S

A-20-K

A-20-S

A-20

A-10-K

A-10-S

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
A-30-K/-S	PWSYXE8	AC 220 V to 230 V	
A-20-K/-S	PWSYXE8	AC 220 V to 230 V	
A-20	CUXE	AC 120 V	
A-10-K/-S	SYXE8	AC 220 V to 230 V	



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
 ©PIONEER CORPORATION 2012

K-FZV MAY 2012 Printed in Japan

(2) CONTRAST TABLE

A-30-K/PWSYXE8, A-30-S/PWSYXE8, A-20-K/PWSYXE8, A-20-S/PWSYXE8 and A-20/CUXE are constructed the same except for the following:

Mark	No.	Symbol and Description	A-30-K/ PWSYXE8	A-30-S/ PWSYXE8	A-20-K/ PWSYXE8	A-20-S/ PWSYXE8	A-20/ CUXE
A	1	MAIN ASSY	AZW7487	AZW7487	AZW7489	AZW7489	AZW7490
	2	FRONT ASSY	AZW7482	AZW7482	AZW7483	AZW7483	AZW7484
	3	MASTER VOLUME ASSY	AZW7476	AZW7476	AZW7481	AZW7481	AZW7481
	7	Power Knob	CBT1A1162	CBT1A1162C81	CBT1A1162	CBT1A1162C81	CBT1A1162
	8	Funktion Knob	CBT1A1163	CBT1A1163MQG69	CBT1A1163	CBT1A1163MQG69	CBT1A1163
	9	Balance Knob	CGK1A164ZA	CGK1A164YA	CBN1A260	CBN1A260MQG69	CBN1A260
	10	Volume Knob	CGK1A165ZA	CGK1A165YA	CBN1A262	CBN1A262MQG69	CBN1A262
	11	Input Knob	CGK2A164ZA	CGK2A164YA	CBN1A261	CBN1A261MQG69	CBN1A261
	12	IR Window	CGL1A295Z	CGL1A295	CGL1A295Z	CGL1A295	CGL1A295Z
	16	Sub Panel	CGW1A517	CGW1A517MQG69	CGW1A517	CGW1A517MQG69	CGW1A517
	26	AC Inlet	CJJ8A006ZW	CJJ8A006ZW	CJJ8A018Z	CJJ8A018Z	Not used
	27	Top Cabinet	CKC2A214B62	CKC2A214G70	CKC2A214B62	CKC2A214G70	CKC2A214B62
	28	Rear Panel	CKF1A452Z	CKF1A452R	CKF2A452X	CKF2A452Q	CKF4A452W
	29	Insulator	CKL1A204	CKL1A204H65	CKL1A204	CKL1A204H65	CKL1A204
	30	AL Panel	CKM1A243ZC79	CKM1A243YC80	CKM2A243XC79	CKM2A243WC80	CKM2A243VC79
B	31	Power Transformer	CLT5U050ZE	CLT5U050ZE	CLT5R043ZE	CLT5R043ZE	CLT5R043ZU
	34	Pioneer Badge (AL)	BAM1004	VAM1124	BAM1004	VAM1124	PAN1376
	35	AC Inlet Wire (SY)	Not used	Not used	CWZA10CN96A	CWZA10CN96A	Not used
	38	Power Cord (CU)	Not used	Not used	Not used	Not used	CJA523FBYA
	41	Screw	BBZ30P080FTB	CTB3+8JFC	BBZ30P080FTB	CTB3+8JFC	BBZ30P080FTB
	44	Screw	CTB4+6FFZRP	CTB4+6FFCP	CTB4+6FFZRP	CTB4+6FFCP	CTB4+6FFZRP
	45	AC Cord Bushing	Not used	Not used	Not used	Not used	CHR1A028
	46	Screw	CTS3+8JFZR	CTS3+8JR	CTB3+8JFZR	CTB3+8JFZR	CTB3+8JFZR
	52	Screw	CBZ30P080FTB	CBZ30P080FTB	CTB3+8JFZR	CTB3+8JFZR	Not used
	56	Fuse (250V)	CBA2C2000TLEC	CBA2C2000TLEC	CBA2C2000TLEC	CBA2C2000TLEC	CBA2C3150TLEC
C							
D							
E							
F							

9.2 EXTERIOR SECTION (A-30/A-20)

