


Pioneer

Service Manual



A-70-K

ORDER NO.
RRV4385

INTEGRATED AMPLIFIER

A-70-K

A-70-S

A-50-K

A-50-S

A-50

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
A-70-K/-S	SYXE8	AC 220 V to 230 V	
A-50-K/-S	SYXE8	AC 220 V to 230 V	
A-50	FXE	AC 110 V	



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2012

K-FZV NOV. 2012 Printed in Japan


(1) EXTERIOR SECTION (A-70) PARTS LIST

	Mark No.	Description	Part No.	Mark No.	Description	Part No.
A	NSP 1	FRONT ASSY	COP12478B	31	Top Cabinet	See Contrast table (2)
	2	PCB GUIDE -8	COP12478B-9	32	Rear Panel	See Contrast table (2)
	3	D-AMP ASSY	AZW7694	33	Foot	See Contrast table (2)
	4	D-AMP SUB ASSY	AZW7696	34	Side Panel L	See Contrast table (2)
	NSP 5	MAIN ASSY	COP12479C	35	Side Panel R	See Contrast table (2)
	6	INPUT ASSY	AZW7669	36	Ground Terminal	CMA1A006
	7	PHONO ASSY	AZW7671	37	Insulator (PC,CU,PC)	CMX1A322
	8	USB ASSY	AZW7673	38	Heat Sink Sheet	CMZ1A143
	9	AC LINE ASSY	AZW7677	39	Locker Black	CRE1A037
	10	PCB GUIDE -1	COP12479C-5	40	Locker Red	CRE1A037Y
B	11	PCB GUIDE -2	COP12479C-7	41	Rivet Base	CRE1A114
	12	PCB GUIDE -3	COP12479C-8	42	Rivet Pin	CRE1A115
	13	PCB GUIDE -10	COP12479C-9	43	Bottom Plate	CUA1A341B62
	NSP 14	POWER ASSY	COP12480C	44	Acetate Tape	C4FS101BL
	15	POWER ASSY	AZW7687	45	Wire Cushion	CHG1A547
	16	SUB INPUT ASSY	AZW7691	46	Wire Cushion	CHG1A548
	17	CONNECTOR ASSY	AZW7693	47	Wire Cushion	CHG1A572
	18	PCB GUIDE -4	COP12480C-4	48	Clamper	CHR301
C	19	PCB GUIDE -5	COP12480C-5	49	•••••	
	20	PCB GUIDE -6	COP12480C-6	50	PCB Insulator	CMX1A313
	21	PCB GUIDE -7	COP12480C-7	51	Screw	ABZ30P060FTC
	⚠ 22	Power Trans (Main)	CLT5U053ZE	52	Screw	BBZ30P060FTC
	⚠ 23	Power Trans (Pre)	CLT5M041ZE	53	•••••	
	24	Foot Cushion	CHG1A528	54	Special Screw	See Contrast table (2)
	25	Screw Cushion	CHG1A576	55	Special Screw	CHD2A060R
	26	Wire Clamp	CRE1A110	56	Trans Screw	CHD3A023R
	27	Hemelon Tape	CHS1A032	57	Screw	CTB3+10JFZR
	28	Cover Sheet	CHS1A154	58	Screw	CTB3+6JFZR
	29	Acetate Tape (10 x 15)	CHS1A217	59	Screw	CTB3+8JFZR
D	30	Short Pin Plug	CJT1A100	60	Screw	CTB4+10GFZR
				61	Screw	See Contrast table (2)
	NSP 62	Serial Label S				VRW2017

(2) CONTRAST TABLE

A-70-K/SYXE8 and A-70-S/SYXE8 are constructed the same except for the following:

Mark No.	Symbol and Description	A-70-K/SYXE8	A-70-S/SYXE8
E	31	Top Cabinet	CKC1A217B62
	32	Rear Panel	CKF1A460Y
	33	Foot	CKL1A204
	34	Side Panel L	CKM1A252C79
	35	Side Panel R	CKM1A253C79
	54	Special Screw	CHD1A080FFZRP
	61	Screw	CTB3+8JFZR



A-70-K

55