

Pioneer

Service Manual



XV-BD422B

ORDER NO.
RRV4334

Blu-ray Disc receiver

XV-BD422B

XV-BD122B

XV-BD122FSB

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	DVD Region No.	BD Region No.	Serial No.	Remarks
XV-BD422B	YXE8	AC 110 V to 240 V	2	B	&&&&#####YY	YY: Europe
XV-BD422B	VXE8	AC 110 V to 240 V	2	B	&&&&#####GB	GB: U.K
XV-BD122B	YXE8	AC 110 V to 240 V	2	B	&&&&#####YY	YY: Europe
XV-BD122B	VXE8	AC 110 V to 240 V	2	B	&&&&#####GB	GB: U.K
XV-BD122FSB	YXE8	AC 110 V to 240 V	2	B	&&&&#####YY	YY: Europe



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan

PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.


PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium

PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936

©PIONEER CORPORATION 2012

K-MZV JULY 2012 Printed in Japan

3.3 PCB LOCATIONS



08-BCS727-FVY

NOTES: ● Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
● The Δ mark found on some component parts indicates the importance of the safety factor of the part.
Therefore, when replacing, be sure to use parts of identical designation.

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
LIST OF ASSEMBLIES							
	1..	MAIN BOARD ASSY	08-H555DU-MA1R/XXV		1..	AV BOARD ASSY	AZW7613
	1..	FRONT BOARD ASSY	08-BCS727-FVY		1..	SYSTEM POWER SUPPLY ASSY	08-K250HE-PW1
	1..	AMP BOARD ASSY (XV-BD422B, XV-BD122B)	AZW7611			LOADER ASSY	08-LTCA19-222026
	1..	AMP BOARD ASSY (XV-BD122FSB)	AZW7612				

XV-BD422B