

Pioneer

Service Manual



BDP-3220K

ORDER NO.
RRV4415

Blu-ray 3D™ PLAYER

BDP-3220K

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	DVD Region No.	BD Region No.	Serial No.	Remarks
BDP-3220K	SXE	AC 110 V to 240 V	5	C	&&&&#####UR	UR:Russia
BDP-3220K	LXE	AC 110 V to 240 V	3	A	&&&&#####LL	LL:Asean
BDP-3220K	AXQ5	AC 110 V to 240 V	6	C	&&&&#####CN	CN:China



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan

PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.


PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium

PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936

©PIONEER CORPORATION 2013

K-FZV MAR. 2013 Printed in Japan

3.2 PCB LOCATIONS



NOTES: ● Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
 ● The ⚠ mark found on some component parts indicates the importance of the safety factor of the part.
 Therefore, when replacing, be sure to use parts of identical designation.

Mark	No.	Description	Part No.
LIST OF ASSEMBLIES			
	1..	MAIN BOARD ASSY(SXE)	08-BD3220-MB1/S-TL
	1..	MAIN BOARD ASSY(LXE)	08-BD3220-MB0/L-TL
	1..	MAIN BOARD ASSY(AXQ5)	08-BD3220-MB0/A-TL
⚠	1..	POWER/FRONT BOARD ASSY	08-BD3220-PF0-TL
	1..	Loader Assy	08-LTCBC9-222416-TL

3.3 JIGS LIST

Name	Jig No.	Remarks
DVD Test Disc (DVD-Video)	GGV1025	Check of DVD-Video
BD-ROM Test Disc	GGV1350	Check of BD-ROM
BD-ROM Test Disc (One layer type)	GGV1368	For Adjustment
Service Jig	GGF1676 (Including a USB cable)	Refer to " 8.6 METHOD OF READING OUT AND WRITING BARCODE DATA BY USING PC AND SERVICE JIG "