

Pioneer

Service Manual



BDP-LX55

ORDER NO.
RRV4285

Blu-ray 3D™ PLAYER

BDP-LX55

BDP-53FD

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	DVD Region No.	BD Region No.	Serial No.	Remarks
BDP-LX55	YXCN5	AC 100 V to 240 V	2	B	&&&&####YY	YY:Europe
BDP-LX55	VXCN5	AC 100 V to 240 V	2	B	&&&&####GB	GB:U.K
BDP-LX55	FWLXCN	AC 100 V to 240 V	3	A	&&&&####TA	TA:Taiwan
BDP-53FD	UCXCN	AC 120 V	1	A	&&&&####UC	UC:NORTH AMERICA




PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936

©PIONEER CORPORATION 2012

K-FZV MAR. 2012 Printed in Japan

9.2 EXTERIOR SECTION



(1) EXTERIOR SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	FRONT BOARD ASSY	08-BDLX55-FV0	NSP 16	AC Inlet	AKP7213
2	MAIN BOARD ASSY	See Contrast table (2)	17	CD Door ASSY	See Contrast table (2)
3	POWER BOARD ASSY	See Contrast table (2)	18	Front Cabinet ASSY	See Contrast table (2)
4	SWITCH BOARD ASSY	08-BDLX55-SW0-TL	19	Rubber Foot	54-106480-000-TL
5	RS BOARD ASSY	08-BDP440-RS0-TL	20	Bottom Cabinet	67-BD14R1-2E0
6	Loader ASSY	08-BL2000-LD4-TL	21	Back Plate	See Contrast table (2)
7	FFC 220mm	46-EE022C-45BU-TL	22	Top Cover	67-BD44T1-1E0B1
8	FFC 8pin 80mm	46-FF008C-08BV	23	Insulator	See Contrast table (2)
9	Cable 7pin 360mm	46-FF036T-07H	24	S/T Screw B 2.6 X 6 BF	63-B26060-BF4-TL
10	Cable 4pin 60mm	46-FH006T-04SA	25	S/T Screw B 3.6	63-B30060-3H3-TL
11	Cable 3pin 100mm	46-FH010T-03P-TL	26	ST Screw B 3 X 6 Silver	63-B30060-3H4-TL
12	Cable 4pin 100mm	46-FH010T-04MA	27	Triangle M/C Screw B 3 X 4	64-B30040-3H4-TL
13	Cable 4pin 100mm	46-FH010T-04S	28	Triangle M/C Screw B 3 X 4	64-B30040-3H8-TL
14	Cable 12pin 160mm	46-FH016T-12S	29	Screw B 3 X 7 BF	63-B30070-3H4-TL
15	Cable 2pin 60mm	46-KL006T-03EC	30	S/T Screw B 3 X 8 BF	63-B30080-BF3-TL
			31	Serial Label	*****

(2) CONTRAST TABLE

BDP-LX55/YXCN5, BDP-LX55/VXCN5, BDP-LX55/FWLXCN and BDP-53FD/UCXCN are constructed the same except for the following:

Mark No.	Symbol and Description	BDP-LX55/ YXCN5	BDP-LX55/ VXCN5	BDP-LX55/ FWLXCN	BDP-53FD/ UCXCN
2	MAIN BOARD ASSY	08-BDLX55-MA0/Y	08-BDLX55-MA0/Y	08-BDLX55-MA0/F	08-BDLX55-MA0/U
3	POWER BOARD ASSY	08-BDLX55-PW2	08-BDLX55-PW2	08-BDLX55-PW0	08-BDLX55-PW1
17	CD Door ASSY	08-BDLX55-DA1	08-BDLX55-DA1	08-BDLX55-DA1	08-BDLX55-DA2
18	Front Cabinet ASSY	08-BDLX55-FA0	08-BDLX55-FA0	08-BDLX55-FA0	08-BDLX55-FA1
21	Back Plate	67-BD44B2-0E0B1	67-BD44B2-0E0B1	67-BD44B2-0E0B6	67-BD44B2-0E0B2
23	Insulator	56-BD44E1-0HAB2	56-BD44E1-0HAB2	56-BD44E1-0HAB2	56-BD44E1-0HA

