


Pioneer

Service Manual



BDP-140

ORDER NO.
RRV4263

Blu-ray 3D™ PLAYER

BDP-140

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).


Model	Type	Power Requirement	DVD Region No.	BD Region No.	Remarks
BDP-140	YXCN5	AC 100V to 240V	2	B	
BDP-140	VXCN5	AC 100V to 240V	2	B	
BDP-140	UCXCNSM	AC 100V to 240V	1	A	



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
 ©PIONEER CORPORATION 2011

K-FZV SEP. 2011 Printed in Japan

3.2 PCB LOCATIONS



NOTES: ● Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
 ● The ⚠ mark found on some component parts indicates the importance of the safety factor of the part.
 Therefore, when replacing, be sure to use parts of identical designation.

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
LIST OF ASSEMBLIES							
	1.	MAIN BOARD ASSY (YXCN5,VXCN5)	08-BDP140-MAQ/Y-TL	⚠	1.	POWER BOARD ASSY(YXCN5,VXCN5)	08-BDP140-PW0-TL
	1.	MAIN BOARD ASSY (UCXCNSM)	08-BDP140-MAQ/U-TL	⚠	1.	POWER BOARD ASSY(UCXCNSM)	08-BDP140-PW1-TL
	1.	FRONT BOARD ASSY	08-BDP140-FV0-TL			1..Loader ASSY	08-BL2000-LD4-TL
	1.	SWITCH BOARD ASSY	08-BDP140-SW0-TL				
	1.	AV BOARD ASSY	08-BDP130-AV0-TL				

3.3 JIGS LIST

Name	Jig No.	Remarks
DVD Test Disc (DVD-Video)	GGV1025	Check of DVD-Video
BD-ROM Test Disc	GGV1350	Check of BD-ROM
BD-ROM Test Disc (One layer type)	GGV1368	For Adjustment
Emergency Disc Ejection Rod	GGF1529	Emergency disc ejection