

Service Manual



HRM-6



HRM-5

ORDER NO.
RRV4652

PROFESSIONAL REFERENCE MONITOR HEADPHONES

HRM-6 /XEGWL

HRM-5 /XEGWL

1. SPECIFICATIONS

HRM-6

Type Fully enclosed dynamic headphones
Impedance 45 Ω
Sensitivity 102 dB
Frequency response 5 Hz to 40 000 Hz
Maximum input power 2 000 mW
Driver units ϕ 40 mm dome type
Plug ϕ 3.5 mm stereo mini-plug
(gold plated, threaded type)
Head cushion Polyurethane (leather finish)
Ear pad Polyurethane (leather finish)
Weight 265 g (without cord)
Accessories ϕ 6.3 mm standard stereo plug adapter
(gold plated, threaded type),
Carrying pouch,
1.2 m long one-side connection coiled type
(extended length 3.0 m),
3.0 m straight cable, 1.2 m straight cable

NOTE:

Specifications and design are subject to possible modifications without notice due to improvements.

HRM-5

Type Fully enclosed dynamic headphones
Impedance 32 Ω
Sensitivity 100 dB
Frequency response 5 Hz to 30 000 Hz
Maximum input power 1 700 mW
Driver units ϕ 40 mm dome type
Plug ϕ 3.5 mm stereo mini-plug
(gold plated, threaded type)
Head cushion Polyurethane (leather finish)
Ear pad Polyurethane (leather finish)
Weight 260 g (without cord)
Accessories ϕ 6.3 mm standard stereo plug adapter
(gold plated, threaded type),
Carrying pouch,
1.2 m long one-side connection coiled type
(extended length 3.0 m),
3.0 m straight cable

NOTE:

Specifications and design are subject to possible modifications without notice due to improvements.

About the label of production lot

The label of production lot is attached L side SP BASE ASSY.
It is printed production year and week.



1620

20 : 20 weeks of year
16 : 2016

Pioneer DJ Corporation

6F, Yokohama Mark Place, 4-4-5 Minatomirai, Nishi-ku, Yokohama, Kanagawa 220-0012, JAPAN

2. EXPLODED VIEWS AND PARTS LIST

NOTES: ● Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
● The  mark found on some component parts indicates the importance of the safety factor of the part.
Therefore, when replacing, be sure to use parts of identical designation.

2.1 EXPLODED VIEWS



EXPLODED VIEWS Parts List

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	EAR PAD (HRM-6)	26.00P6-2800	5	HEADBAND ASSY (HRM-6)	12.00P6-2001
1	EAR PAD (HRM-5)	26.00P5-2800	5	HEADBAND ASSY (HRM-5)	12.00P5-2002
2	SP BASE ASSY L (HRM-6)	12.00P6-A000	6	SCREW	33.2035-2101
2	SP BASE ASSY L (HRM-5)	12.00P5-A000	7	SCREW	33.2060-2100
3	SP BASE ASSY R (HRM-6)	12.00P6-A001			
3	SP BASE ASSY R (HRM-5)	12.00P5-A001			
4	JACK ASSY	12.00P6-8000			

* There is no need for the measuring instrument or jigs, when replacing the parts.
* JACK ASSY includes the internal cord.