


Pioneer

Service Manual



AVH-3500DVD/XEUC

ORDER NO.
CRT5348

DVD AV RECEIVER

AVH-3500DVD /XEUC

AVH-3550DVD /XERD

AVH-3550DVD /XERC

AVH-3550DVD /XERI

AVH-3500DVD /XEUW5




PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2013

K-ZZZ JULY 2013 Printed in Japan

Service remedy

- 1 Insert the new FPC through the SHEET and assemble them as shown below.




- 2 Fix the SHEET by the screws as shown below.
Top side



121460000674

The condition of the back side.



- 3 Insert the FPC to the connector and fix the FPC by the SHEET (Tape) as shown below.

