


Pioneer

Service Manual



AVH-3500DVD/XEUC

ORDER NO.
CRT5348

DVD AV RECEIVER

AVH-3500DVD /XEUC

AVH-3550DVD /XERD

AVH-3550DVD /XERC

AVH-3550DVD /XERI


AVH-3500DVD /XEUW5



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2013

K-ZZZ JULY 2013 Printed in Japan

9.3 EXTERIOR (2)



AVH-3500DVD/XEUC

5 6 7 8

EXTERIOR (2) SECTION PARTS LIST

Mark No.	Description	Part No.
1	Holder	121000003712
2	Holder	121000003713
3	Screw	121045000007
4	Screw	121045000040
5	Screw	121100070098
6	Screw	121104050023
7	Screw	121106070011
8	Gasket	121405000311
9	Spacer	121410000510
10	Sheet	121455010113
11	FPC	123020010136
12	Grille	141210001672018
13	Cover	141210101676018
14	Touch Panel	143420000079
15	TFT LCD	143420020069
16	DVD Mechanism Module	843DV7791GASB004 (NOTE 1)
17	TFT PCB Assy	843DV7791GATFT004
18	Insulator	121415000227
19	FFC	143820000240
20	Sheet	121490000888 (NOTE 2)
21	Gasket	121405000348

(NOTE 1)

Any component parts in the DVD Mechanism Module can not be supplied. If you need to replace any parts in the DVD Mechanism Module, replace whole of DVD Mechanism Module.

(NOTE 2)

This part is not reusable. If you remove this sheet, replace it with the new one.