

Pioneer

Service Manual



AVH-3800DVD/XEUR

ORDER NO.
CRT5757

DVD AV RECEIVER

AVH-3800DVD/XEUR

AVH-3850DVD/XERD

AVH-3850DVD/XERI



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2015

K-ZZZ JUNE 2015 Printed in Japan

9.2 EXTERIOR (1)

This diagram illustrates the exterior assembly of the AVH-3800DVD/XEUR car stereo. It shows the main unit (9) being installed into a dashboard (29) using a mounting bracket (12) and screws (10, 11, 13). The front faceplate (28) is attached to the unit. Various cables are connected to the rear of the unit: a 3800DVD/XEUR cable (31) for the main unit, a 3850DVD/XERD/3850DVD/XERI cable (21) for the remote control (30), and a multi-pin cable (32) for other accessories. The diagram also shows the installation of a trim plate (26) and a power antenna cable (25). A yellow callout box with the number 12485000030 points to a specific screw location. The diagram is labeled with letters A, B, C, D, E, and F, and numbers 1 through 32.

3800DVD/XEUR
31

3850DVD/XERD
3850DVD/XERI
21

30

32

26

12485000030

AVH-3800DVD/XEUR