


**Pioneer**

# Service Manual



AVH-3500DVD/XEUC

ORDER NO.  
**CRT5348**

DVD AV RECEIVER

**AVH-3500DVD** /XEUC**AVH-3550DVD** /XERD**AVH-3550DVD** /XERC**AVH-3550DVD** /XERI**AVH-3500DVD** /XEUW5

**PIONEER CORPORATION** 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan  
**PIONEER ELECTRONICS (USA) INC.** P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.  
**PIONEER EUROPE NV** Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium  
**PIONEER ELECTRONICS ASIACENTRE PTE. LTD.** 253 Alexandra Road, #04-01, Singapore 159936  
©PIONEER CORPORATION 2013

K-ZZZ JUNE 2013 Printed in Japan

**(1) EXTERIOR (1) SECTION PARTS LIST**


| <u>Mark No.</u> | <u>Description</u>       | <u>Part No.</u>        | <u>Mark No.</u> | <u>Description</u> | <u>Part No.</u>        |
|-----------------|--------------------------|------------------------|-----------------|--------------------|------------------------|
| 1               | Card Remote Control Unit | See Contrast table (2) | 12              | Door               | 121290002710000        |
| 2               | Battery Cover            | See Contrast table (2) | 13              | Gasket             | 121405000340           |
| 3               | Holder                   | 121000004013           | 14              | Button (CLOSE)     | 141230004232018        |
| 4               | Bracket                  | 121000004133           | 15              | Button (SRC/-OFF)  | 141230004233018        |
| 5               | Screw                    | 121040000222           | 16              | Knob               | 141230504243017        |
| 6               | Screw                    | 121045000007           | 17              | Keyboard Assy      | 843DV7791GAKB004       |
| 7               | Screw                    | 121045040062           | 18              | Spacer             | 121240001542000        |
| 8               | Screw                    | 121100020159           | 19              | Sheet              | 121445000313           |
| 9               | Button (TRK, WIDE)       | 121230004230000        | 20              | FFC                | 123820000495           |
| 10              | Bracket                  | 121240001541000        | 21              | Cord Assy          | See Contrast table (2) |
| 11              | Panel                    | 121270100865018        | 22              | Grille Unit        |                        |
|                 |                          |                        |                 | 883DV7791GBMK000   |                        |

**(2) CONTRAST TABLE**

AVH-3500DVD/XEUC, AVH-3500DVD/XEUW5, AVH-3550DVD/XERC, AVH-3550DVD/XERD and AVH-3550DVD/XERI are constructed the same except for the following:

| Mark | No. | Description              | AVH-3500DVD/<br>XEUC | AVH-3500DVD/<br>XEUCW5 | AVH-3550DVD/<br>XERC | AVH-3550DVD/<br>XERD | AVH-3550DVD/<br>XERI |
|------|-----|--------------------------|----------------------|------------------------|----------------------|----------------------|----------------------|
|      | 1   | Card Remote Control Unit | CXE5116              | Not used               | CXE5116              | CXE5116              | CXE5116              |
|      | 2   | Battery Cover            | CNU1624              | Not used               | CNU1624              | CNU1624              | CNU1624              |
|      | 21  | Cord Assy                | 843DV7791GAPWR004    | 843DV7791GRPWR004      | 843DV7791GAPWR004    | 843DV7791GAPWR004    | 843DV7791GAPWR004    |

## 9.2 EXTERIOR (1)



AVH-3500DVD/XEUC