


Pioneer

Service Manual



AVH-3500DVD/XEUC

ORDER NO.
CRT5348

DVD AV RECEIVER

AVH-3500DVD /XEUC**AVH-3550DVD** /XERD**AVH-3550DVD** /XERC**AVH-3550DVD** /XERI**AVH-3500DVD** /XEUW5**PIONEER CORPORATION** 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan**PIONEER ELECTRONICS (USA) INC.** P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.**PIONEER EUROPE NV** Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium**PIONEER ELECTRONICS ASIACENTRE PTE. LTD.** 253 Alexandra Road, #04-01, Singapore 159936


©PIONEER CORPORATION 2013

K-ZZZ JUNE 2013 Printed in Japan

EXTERIOR (2) SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	
1	Holder	121000003712	
2	Holder	121000003713	
3	Screw	121045000007	A
4	Screw	121045000040	
5	Screw	121100070098	
6	Screw	121104050023	
7	Screw	121106070011	
8	Gasket	121405000311	
9	Spacer	121410000510	
10	Sheet	121455010113	
11	FPC	123020010136	B
12	Grille	141210101672028	
13	Cover	141210101676028	
14	Touch Panel	143420000079	
15	TFT LCD	143420020069	
16	DVD Mechanism Module	843DV7791GASB004	
17	TFT PCB Assy	843DV7791GATFT004	
18	Insulator	121415000227	
19	FFC	143820000240	
			C
			D
			E
			F

9.3 EXTERIOR (2)



AVH-3500DVD/XEUC