

Pioneer

Service Manual



S-DJ80X

ORDER NO.
RRV4488

ACTIVE REFERENCE MONITOR

S-DJ80X

S-DJ60X

S-DJ50X

S-DJ50X-W

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
S-DJ80X	SYXE8	AC 220 V to 240 V	
S-DJ80X	CMXE	AC 120 V	
S-DJ80X	FWPWXE	AC 100 V to 120 V or 220 V to 240 V	
S-DJ80X	AXE5	AC 220 V to 240 V	
S-DJ60X	SYXE8	AC 220 V to 240 V	
S-DJ60X	CMXE	AC 120 V	
S-DJ60X	FWPWXE	AC 100 V to 120 V or 220 V to 240 V	
S-DJ60X	AXE5	AC 220 V to 240 V	
S-DJ50X, S-DJ50X-W	SYXE8	AC 220 V to 240 V	
S-DJ50X, S-DJ50X-W	CMXE	AC 120 V	
S-DJ50X, S-DJ50X-W	FWPWXE	AC 100 V to 120 V or 220 V to 240 V	
S-DJ50X, S-DJ50X-W	AXE5	AC 220 V to 240 V	



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2013

K-MZV OCT. 2013 Printed in Japan

9.2 EXTERIOR SECTION

9.2.1 S-DJ80X

A




B

C

D

E

F



200103000020