

# Pioneer

## Service Manual



BDP-160-K

ORDER NO.  
**RRV4456**

Blu-ray 3D™ PLAYER


# BDP-160-K

## BDP-160-S

## BDP-160

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

| Model     | Type | Power Requirement | DVD<br>Region No. | BD<br>Region No. | Serial No. | Remarks      |
|-----------|------|-------------------|-------------------|------------------|------------|--------------|
| BDP-160-K | YXE8 | AC 110 V to 240 V | 2                 | B                | &&&&####YY | YY : Europe  |
| BDP-160-K | VXE8 | AC 110 V to 240 V | 2                 | B                | &&&&####GB | GB : U.K     |
| BDP-160-S | YXE8 | AC 110 V to 240 V | 2                 | B                | &&&&####YY | YY : Europe  |
| BDP-160   | FXE  | AC 110 V to 240 V | 3                 | A                | &&&&####TA | TA : Taiwan  |
| BDP-160   | LXE  | AC 110 V to 240 V | 3                 | A                | &&&&####LL | LL : Asean   |
| BDP-160   | PWXE | AC 110 V to 240 V | 4                 | B                | &&&&####PP | PP : Oceania |
| BDP-160   | SXE  | AC 110 V to 240 V | 5                 | C                | &&&&####UR | UR : Russia  |
| BDP-160   | AXQ5 | AC 110 V to 240 V | 6                 | C                | &&&&####CN | CN : China   |



**PIONEER CORPORATION** 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan  
**PIONEER ELECTRONICS (USA) INC.** P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.  
**PIONEER EUROPE NV** Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium  
**PIONEER ELECTRONICS ASIACENTRE PTE. LTD.** 253 Alexandra Road, #04-01, Singapore 159936  
©PIONEER CORPORATION 2013

K-ZZZ JULY 2013 Printed in Japan

## &lt; Service Remedy &gt;

If the serial number falls in the following ranges and the symptom can be recovered by pressing the reset button on front panel, replace the C214 with new part "28-AF0106-MBX".

Serial Number

|                   |          |            |
|-------------------|----------|------------|
| - BDP-160/AXQ5    | 000001CN | - 015756CN |
| - BDP-160/FXE     | 000001TA | - 003000TA |
| - BDP-160/LXE     | 000001LL | - 004504LL |
| - BDP-160/PW/XE   | 000001PP | - 014302PP |
| - BDP-160/SXE     | 000001UR | - 005700UR |
| - BDP-160-K/V/XE8 | 000001GB | - 001700GB |
| - BDP-160-K/Y/XE8 | 000001YY | - 024800YY |
| - BDP-160-S/Y/XE8 | 000001YY | - 003906YY |

Reset ButtonLocation of C214