Pioneer

Service Manual



PLX-1000

ORDER NO.
RRV4511

TURNTABLE

PLX-1000

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
PLX-1000	LPSYXE8	AC 110 V to 120 V or 220 V to 240 V	
PLX-1000	FUXECB	AC 110 V to 120 V or 220 V to 240 V	

PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2014

K-MZV AUG. 2014 Printed in Japan

10. SCHEMATIC DIAGRAM

10.1 MAIN PCB, SEARCHLIGHT and SPEED PCB ASSYS