Pioneer

Service Manual

DDJ-SR

ORDER NO.
RRV4499

DJ Controller

DDJ-SR

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
DDJ-SR	CKSUVYXE5	DC 5 V (USB-bus power only)	
DDJ-SR	XECN5	DC 5 V (USB-bus power only)	

PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2013

K-MZV NOV. 2013 Printed in Japan


418-DJM250-674
C CN1A
D MIXER PCB ASSY
(704-SR-A597)
E CROSS FADER PCB ASSY
(704-DJM250-A032)