

Pioneer

Service Manual

ORDER NO.
RRV4316

AV Receiver

VSX-827-K

VSX-527-K

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
VSX-827-K	SYXE8	AC 220 V to 230 V	
VSX-527-K	SYXE8	AC 220 V to 230 V	

This service manual should be used together with the following manual(s).

Model No.	Order No.	Remarks
VSX-1022-K/CUXESM	RRV4306	VSX-822-K/CUXESM

For SPECIFICATIONS and PANEL FACILITIES, refer to the operating instructions.

Mark	No.	Symbol and Description	VSX-1022-K/CUXESM	VSX-827-K/SYXE8	Remarks
⚠	P76-35	Back Chassis	3207214196000S-IL	3207214196100-IL	No. 62 No. 63 No. 64
	P76-36	Foot	4000210391000-IL	4007210391000-IL	
		Socket,Power AC	Not used	G430040560021-IL	
		Screw	Not used	CBZ30P080FTB	
		Front Video Plate827	Not used	4470212536000-IL	

Notes : The numbers in the remarks column correspond to the numbers on the "EXPLODED VIEWS".
For PCB ASSEMBLIES, Refer to "CONTRAST OF PCB ASSEMBLIES".

VSX-527-K/SYXE8

VSX-822-K/CUXESM and VSX-527-K/SYXE8 are constructed the same except for the following:

Mark	No.	Symbol and Description	VSX-822-K/CUXESM	VSX-527-K/SYXE8	Remarks
NSP	P76-1	PCB ASSEMBLIES			B
		1..PCB TTL ASSY MAIN	7025HK1107010-IL	7025HK1107020-IL	
		2..MAIN Assy	7028071611010-IL	7028071611020-IL	
	P76-8	1..PCB TTL ASSY FRONT	7025HK1108011-IL	7025HK1108031-IL	
NSP	P76-14	2..FRONT Assy	7028071621030-IL	7028071621040-IL	C
		1..PCB TTL ASSY VIDEO	7025HK1107012-IL	7025HK1107022-IL	
	P76-15	2..VIDEO Assy	7028071671010-IL	7028071671020-IL	
		2..STBY Assy	7028071672010-IL	7028071672020-IL	
NSP	P76-18	1..PCB TTL ASSY AUDIO	7025HK1107013-IL	7025HK1107023-IL	D
		2..AUDIO Assy	7028071641010-IL	7028071641020-IL	
	P76-20	1..PCB TTL ASSY DMAIN	7025HK1107014-IL	7025HK1107024-IL	
		1..PCB TTL ASSY CPU	7025HK1107015-IL	7025HK1107025-IL	
NSP	P76-21	2..CPU Assy	7028071681010-IL	7028071681020-IL	E
		1..PCB TTL ASSY AMP5	7025HK1107017-IL	7025HK1107027-IL	
	P76-21	2..AMP5 Assy	7028070245010-IL	7028070246010-IL	
		PACKING SECTION			
NSP	P73-1	Remote Control (AXD7661)	8300766100010-IL	Not used	F
	P73-1	Remote Control (AXD7662)	Not used	8300766200010-IL	
	P73-5	iPod Cable	L308102013030-IL	Not used	
	P73-6	Operating Instructions (CD-ROM)	6517000000490-IL	6517000000520-IL	
NSP	P73-7	Operating Instructions (En)(PDF)	ARB7470	ARB7471	G
		Operating Instructions (Fr)(PDF)	ARC8044	ARC8046	
	P73-8	Operating Instructions (De)(PDF)	Not used	ARC8047	
		Operating Instructions (It)(PDF)	Not used	ARC8048	
NSP	P73-11	Operating Instructions (Es)(PDF)	ARC8045	ARC8049	H
		Operating Instructions (Ni)(PDF)	Not used	ARC8050	
	P73-11	Operating Instructions (Ru)(PDF)	Not used	ARC8051	
		Quick Start Guide	5707000006490-IL	5707000006510-IL	
NSP	P76-24	Box, Gift	6007212070090-IL	60072120700A0-IL	I
	P76-25	Warranty Card	ARY7156	ARY7158	
	P76-34	AC Power Cord	Not used	L068250160020-IL	
	P76-35	EXTERIOR SECTION			
⚠	P76-24	Cord Assy	L068125101710-IL	Not used	J
		Power Trans	8200960611180-IL	8200960611220-IL	
	P76-34	Front Panel	3067215491020-IL	3067215491130-IL	
	P76-35	Back Chassis	3207214186000S-IL	3207214186100-IL	
⚠	P76-35	Socket,Power AC	Not used	G430040560021-IL	K
		Screw	Not used	CBZ30P080FTB	
	P76-35	Front Video Plate827	Not used	4470212536000-IL	

Notes : The numbers in the remarks column correspond to the numbers on the "EXPLODED VIEWS".
For PCB ASSEMBLIES, Refer to "CONTRAST OF PCB ASSEMBLIES".