


Pioneer

Service Manual



XDJ-R1

ORDER NO.
RRV4401

DJ SYSTEM

XDJ-R1

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).


Model	Type	Power Requirement	Remarks
XDJ-R1	SVWYXE8	AC 220 V to 240 V	
XDJ-R1	CUXE	AC 120 V	
XDJ-R1	FLWPWXE	AC 110 V to 120 V or 220 V to 240 V	
XDJ-R1	KXE5	AC 220 V	
XDJ-R1	AXE5	AC 220 V to 240 V	



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2013

K-MZV JUNE 2013 Printed in Japan

3.3 PCB LOCATIONS



NOTES: ● Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
 ● The  mark found on some component parts indicates the importance of the safety factor of the part.
 Therefore, when replacing, be sure to use parts of identical designation.

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
LIST OF ASSEMBLIES							
		I/O ASSY	704-COMBO-A378			SERVO ASSY	704-COMBO-A377
		MIXER ASSY	704-COMBO-A376			SWITCHING POWER	411-COMBO-887
		CH ASSY	704-COMBO-A482				
		CROSS FADER ASSY	704-COMBO-A499			SLOT-IN FEEDER MECHA ASSY	704-MCU300-9997-HA
		USB ASSY	704-COMBO-A381				
		PHONES ASSY	704-COMBO-A379				
		DSP & POWER ASSY	704-COMBO-A531				
		Wi-Fi PCB ASSY	704-COMBO-A380				
		CD1 ASSY	704-COMBO-A375				
		CD2 ASSY	704-COMBO-A476				