

Service Manual

PIONEER
The Art of Entertainment



ORDER NO.
RRV 1608

STEREO TURNTABLE

PL-990

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	The voltage can be converted by the following method.
	PL-990		
KUCXCN1	O	AC120V	_____
WYXCN1	O	AC220 - 240V	_____
WVXCN1	O	AC220 - 240V	_____
WPWXCN1	O	AC220 - 240V	_____
RDXCN1	O	AC110 - 127V/220 - 240V	With the voltage selector

CONTENTS

1. SAFETY INFORMATION	2
2. PACKING, EXPLODED VIEWS AND PARTS LIST	3
3. SCHEMATIC AND PCB CONNECTION DIAGRAMS	7
4. PCB PARTS LIST	10
5. ADJUSTMENTS	11
6. PANEL FACILITIES	12
7. SPECIFICATIONS	12

PIONEER ELECTRONIC CORPORATION

PIONEER ELECTRONICS SERVICE, INC. P.O.Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER ELECTRONIC (EUROPE) N.V. Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 501 Orchard Road, #10-00 Lane Crawford Place, Singapore 0923


4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan

© PIONEER ELECTRONIC CORPORATION 1996

T-FFB JUNE 1996 Printed in Japan

PL-990

2.2 EXTERIOR



NOTE : Screws adjacent to ▼ mark on product are used for disassembly.