

Pioneer

Service Manual

ORDER NO.
RRV4303

STEREO TURNTABLE

PL-990

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
PL-990	YXE8	AC 220 V to 240 V	:
PL-990	UXE	AC 120 V	

This service manual should be used together with the following manual(s).

Model No.	Order No.	Remarks
PL-990/KUCXCN1	RRV1608	

For SPECIFICATIONS and PANEL FACILITIES, refer to the operating instructions.**PIONEER CORPORATION** 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan**PIONEER ELECTRONICS (USA) INC.** P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.**PIONEER EUROPE NV** Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium**PIONEER ELECTRONICS ASIACENTRE PTE. LTD.** 253 Alexandra Road, #04-01, Singapore 159936

©PIONEER CORPORATION 2012

K-ZZZ APR. 2012 Printed in Japan

	1	2		3		4	
	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	
A	NSP 94	Spring Washer		NSP143	Wire (Black 270mm 26#)		
	NSP 95	Spring Washer		NSP144	Lead Wire (yellow UL1007 26#)		
				NSP145	1P Wire(L=215mm,AWM1007,AWG26,white)		
	NSP 96	Washer		146	Micro Switch And Wire Assy	704-L100-412-HA	
	NSP 97	Washer		147	Motor Assy	704-FU701-7467-HA	
	NSP 98	Washer		148	T/T Shaft Assy	703-PXE90-083-HA	
	NSP 99	Washer		149	Gear Assy	701-SL24F-192-HA	
	NSP100	Platter Shaft Assy		150	Arm Assy 704-L100-397	PZX1014	
	101	Spring for Cueing	PZN1085	151	Lifter Set Assy	703-L100-063-HA	
	102	Hinge	PZN1086	152	Dust Cover Assy	701-F601-1407-HA	
B	103	Insert Slider	PZN1087	153	Oil Shaft Set Assy	701-F700-708-HA	
	NSP104	Knob Shaft		154	Micro SW&Wire Assy	704-SL24F-307-HA	
	105	Pin	PZN1088	155	Switch Set Assy	701-SL24F-191-HA	
	106	Spring	PZB1056				
	NSP107	Tonearm Tube		NSP156	Lead Wire(Red,UL1007# 26,L=240mm)		
	108	Return Link Assy	PZN1072	NSP157	Carbon Film Resistor(2.2K Ohm,1/4W,J,T-52)		
	NSP109	Cam Gear Control Assy		158	Rotary VR	704-F900-416-HA	
	NSP110	Platter Shaft Set Assy		159	Stylus Cover	PZP1002	
				160	Stylus	PZP1004	
	NSP111	Cueing Lever Assy		NSP161	FCC Label (UXE)		
C	NSP112	Headshell		NSP162	VFS Label (UXE)		
	NSP113	Tonearm Set		NSP163	65 Label (UXE)		
	NSP114	Rotary Shaft Assy					
	NSP115	Pin for Tonearm Set					
	NSP116	Ceramic Capacitor					
	NSP117	Polystyrene Bag					
	NSP118	Screw					
	NSP119	Ground Sheet					
	NSP120	Wire (for Tonearm Ground)					
	NSP121	Screw					
D	NSP122	Spring					
	123						
	NSP124	Shield Wire (White)					
	NSP125	Shield Wire (Red)					
	NSP126	Plastic Knob					
	NSP127	Variable Resistor					
	NSP128	Screw					
	NSP129	Steel Plate					
	130	Antidazzling Screen	501-F900-1322-HA				
	NSP131	Bar Code					
E	132	Acrylic Plate	PZN1092				
	133	Reflection Sheet	501-F907-1846				
	NSP134	Washer					
	NSP135	Screw					
	136	LED & WIRE P.C.Board	PZX1028				
	NSP137	Steel Ball					
	NSP138	Screw					
	139	Washer	PZB1060				
	NSP140	Rating Label					
	141	Button Shaft Assy	701-F700-231-HA				
F	NSP142	Grounding Shield					

1.2 EXTERIOR SECTION

A * The number inverted to white color is NSP part.


B

C

D

E

F



PL-990