

Pioneer

Service Manual

 ORDER NO.
RRV4343

AV Receiver

VSX-322-K

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
VSX-322-K	SYXE8	AC 220 V to 230 V	
VSX-322-K	DLPWXE	AC 220 V to 240 V	

This service manual should be used together with the following manual(s).

Model No.	Order No.	Remarks
HTP-071/SYXE8	RRV4273	VSX-321-K-P/SYXE8, DLPWXE

For SPECIFICATIONS and PANEL FACILITIES, refer to the operating instructions.

PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan

PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.

PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium


PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936

©PIONEER CORPORATION 2012

K-ZZZ JUNE 2012 Printed in Japan

Pioneer

Service Manual



ORDER NO.
RRV4273

HOME CINEMA PACKAGE

HTP-071

AUDIO/VIDEO MULTI-CHANNEL RECEIVER

VSX-321-K-P

SUBWOOFER

S-22W-P

SPEAKER SYSTEM

S-11-P

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
HTP-071	SYXE8	AC 220 V to 230 V	
HTP-071	CXE	AC 120 V	
HTP-071	DLPWXE	AC 220 V to 240 V	
HTP-071	AXE5	AC 220 V	
VSX-321-K-P	SYXE8	AC 220 V to 230 V	
VSX-321-K-P	CXE	AC 120 V	
VSX-321-K-P	DLPWXE	AC 220 V to 240 V	
VSX-321-K-P	AXE5	AC 220 V	
S-22W-P	_____	_____	
S-11-P	_____	_____	

HTP-071 is a Home Cinema Package and consists of VSX-321-K-P, S-22W-P and S-11-P.



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2011

K-IZV OCT. 2011 Printed in Japan

(1) VSX-321-K-P SECTION PARTS LIST

	Mark No.	Description	Part No.	Mark No.	Description	Part No.
A	1	FRONT Assy	7028071131010-IL	31	Chassis Back	See Contrast table (2)
	2	FUNCT Assy	7028071132010-IL	32	Foot (PLS)	4000210391000-IL
	3	BR1 Assy	7028071133010-IL	33	Bracket	4010056906010-IL
	4	HP Assy	7028071134010-IL	34	Cushion	4050211385000-IL
	5	D-MAIN Assy	7028071161010-IL	35	Cushion	4050211605000-IL
	6	DG Assy	7028071111010-IL	36	•••••	
	7	INPUT Assy	7028071112010-IL	37	•••••	
	8	AMP Assy	7028071141010-IL	38	Support	4070001601010-IL
	9	CNT Assy	7028071151010-IL	39	Clamp MTG	4330000310000-IL
	10	MAIN Assy	See Contrast table (2)	40	Window Display 421U	5077213113000-IL
B	11	STBY Assy	See Contrast table (2)	41	Window Display 321L	5077213123200-IL
	12	G-T Assy	7028071123010-IL	42	Knob	5080212431000-IL
	13	G-H Assy	7028071124010-IL	43	Button	5090213741100-IL
	14	G-L Assy	7028071125010-IL	44	5 Key Button	5090214561000-IL
	15	Socket, Power AC	See Contrast table (2)	45	10 Key Button	5090214571000-IL
	16	Power Trans.	See Contrast table (2)	46	Cover	See Contrast table (2)
	17	Posistor	F320301022240-IL	47	Cover	See Contrast table (2)
	18	Transistor	J5011560P0000-IL	48	•••••	
	19	Transistor	J5032390P0000-IL	49	•••••	
	20	Transistor	J5032390Y0000-IL	50	Screw	BBT30P100FTB
C	21	CN, Wire	See Contrast table (2)	51	Screw	BBT40P080FTB
	22	Cord Assy	See Contrast table (2)	52	Screw	BBZ30P080FTB
	23	Cable, Flat Card 1.25	N712272713480-IL	53	Screw	BBZ30P080FTC
	24	Stopper	See Contrast table (2)	54	Screw	BBZ30P180FTC
	25	Pioneer Badge B (PLS)	XAM3006	55	Screw	BSZ30P040FTB
	26	Sheet	1210210235000-IL	56	Screw Tapping Assy	B018230141H11-IL
	27	•••••		57	Screw, Tap Tite	B020230063B10-IL
	28	•••••		58	Screw	B028940101B11-IL
	29	Cabinet	See Contrast table (2)	59	Screw	See Contrast table (2)
	30	Front Panel	See Contrast table (2)	60	Screw	1500001206010-IL
				61	Screw	1500001456010-IL

(2) CONTRAST TABLE

VSX-321-K-P/SYXE8, CXE, DLPWXE and AXE5 are constructed the same except for the following:

Mark	No.	Symbol and Description	VSX-321-K-P /SYXE8	VSX-321-K-P /CXE	VSX-321-K-P /DLPWXE	VSX-321-K-P /AXE5
E	10	MAIN Assy	7028071121040-IL	7028071121030-IL	7028071121020-IL	7028071121010-IL
	11	STBY Assy	7028071122040-IL	7028071122030-IL	7028071122020-IL	7028071122010-IL
	15	Socket, Power AC	G430040560021-IL	Not used	G430040560021-IL	Not used
	16	Power Trans.	8200858500320-IL	8200858500340-IL	8200858500320-IL	8200858500330-IL
	21	CN, Wire	L000800020220-IL	Not used	L000800020220-IL	Not used
	22	Cord Assy	Not used	L068125101710-IL	Not used	L068250101710-IL
	24	Stopper	Not used	4380040162010-IL	Not used	4380040162010-IL
	29	Cabinet	3007211846000-IL	3007211846000-IL	3007211846100-IL	3007211846000-IL
	30	Front Panel	3067215081140-IL	3067215081010-IL	3067215081140-IL	3067215081140-IL
	31	Chassis Back	3207214056110-IL	3207214056010-IL	3207214056100-IL	3207214056000-IL
F	46	Cover	Not used	Not used	4310212122020-IL	Not used
	47	Cover	Not used	Not used	4310213701000-IL	Not used
	59	Screw	CBZ30P080FTB	Not used	CBZ30P080FTB	Not used

