


Pioneer

Service Manual



DVH-730AV/XZUW5

PROVISIONAL**CRT4714P**

DVD AV RECEIVER

DVH-730AV

 /XZUW5

DVH-735AV

 /XZRD

DVH-735AV

 /XZRI

DVH-7380AV


 /XFBR

For details, refer to "Important Check Points for Good Servicing".

PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan**PIONEER ELECTRONICS (USA) INC.** P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.**PIONEER EUROPE NV** Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium**PIONEER ELECTRONICS ASIACENTRE PTE. LTD.** 253 Alexandra Road, #04-01, Singapore 159936**©PIONEER CORPORATION 2011**

K-ZZZ JULY 2011 Printed in Japan

9.4 MECHANISM



5 6 7 8

(1) MECHANISM PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	Deck	144840010083-FY	7	Screw	121104050032-FY
2	End-Sense SW	143210000004-FY	8	Mat	121410000025-FY
3	Wire Harnes	123830000117-FY	9	Dustproof Cover	121290020962000-FY
4	FFC	143820000228-FY	10	Screw	???????
5	Shield	141000002742-FY	11	DVD Decode Unit	See Contrast table (3)
6	Heat Silica Gel	121490000426-FY			

(2) CONTRAST TABLE

DVH-730AV/XZUW5, DVH-735AV/XZRD, DVH-735AV/XZRI and DVH-7380AV/XFBR are constructed the same except for the following:

<u>Mark No.</u>	<u>Description</u>	<u>DVH-730AV/XZUW5</u>	<u>DVH-735AV/XZRD</u>	<u>DVH-735AV/XZRI</u>	<u>DVH-7380AV/XFBR</u>
11	DVD Decode Unit	842DM7226GRSB002-FY	842DM7226GLSB002-FY	842DM7226GMSB002-FY	882DM7226GBSB002-FY