


Pioneer

Service Manual



DVH-760AV/XEUW5

ORDER NO.
CRT5426

DVD AV RECEIVER

DVH-760AV /XEUW5

DVH-765AV /XERD

DVH-765AV /XERI

DVH-7680AV /XFBR



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2013

K-ZZZ OCT. 2013 Printed in Japan

9.3 EXTERIOR (1) (XEUV5, XERD, XERI)

A


B

C

D

E

F



(1) EXTERIOR (1) (XEUW5, XERD, XERI) SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Detach Panel (Assy)	See Contrast table (2)	18	Slide Block R	14129080071400-FY
* 2	KB Assy	842DM7240GLKB002-FY	19	Spring L/R	121035000136-FY
3	*****		20	Screw	121045000013-FY
4	Poron	121405000151-FY	21	Slide Block L	14129080071300-FY
5	Mat	121405000245-FY	22	Button (BSM)	141230004484000-FY
6	Double Side Tape	121445000326-FY	23	Button (Four Point)	141230004485000-FY
7	Bracket	141000002725-FY	24	Spring	121035000015-FY
8	Shield	141000002728-FY	25	Button (BRK)	141240001661000-FY
9	Bracket	141240001458000-FY	26	Button (Release)	141230004487000-FY
10	TFT/A	123420000137-FY	27	Button (SRC)	141230504483014-FY
11	Cover	141230504482014-FY	28	Button (BAND)	141230004486018-FY
12	Double Side Tape	121445000331-FY	29	Spring	121035000569-FY
13	Knob	121230004481000-FY	30	Panel	141210001796000-FY
14	Lens	See Contrast table (2)	31	Card Remote Control Unit	CXE5124
15	Cover	141290002807000-FY	32	Battery Door	10030-0040600-CG
16	Panel	141210601795017-FY	33	Cord Assy	See Contrast table (2)
17	Button (SEL/ESC)	141230003896028-FY	34	E Cap	141842070107-FY

(2) CONTRAST TABLE

DVH-760AV/XEUW5, DVH-765AV/XERD and DVH-765AV/XERI are constructed the same except for the following:

Mark	No.	Description	DVH-760AV/XEUW5	DVH-765AV/XERD	DVH-765AV/XERI
	1	Detach Panel (Assy)	843DM7240GRKB002-FY	843DM7240GLKB002-FY	843DM7240GLKB002-FY
	14	Lens	141220000717028-FY	141220000717038-FY	141220000717038-FY
	33	Cord Assy	843DM7240GRPWR004-FY	843DM7240GLPWR004-FY	843DM7240GLPWR004-FY