


Pioneer

Service Manual



DVH-760AV/XEUW5

ORDER NO.
CRT5426

DVD AV RECEIVER

DVH-760AV /XEUW5

DVH-765AV /XERD

DVH-765AV /XERI


DVH-7680AV /XFBR



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2013

K-ZZZ OCT. 2013 Printed in Japan

9.5 EXTERIOR (2) (XEUW5, XERD, XERI)



(1) EXTERIOR (2) (XEUW5, XERD, XERI) SECTION PARTS LIST					
Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Screw	121040000054-FY	33	Mat	121405000040-FY
2	Shaft	121030000336-FY	34	Rim	141270000712000-FY
3	Locker	121200000837000-FY	35	Nut	121050000023-FY
4	Washer	121440000031-FY			
5	Gear	141200010082-FY	36	Heat Silica Gel	121490000464-FY
			*	37 CB Assy	843DM7240GLCB002-FY
6	Bracket	141000011868-FY	38	FFC	143820000257-FY
7	Damper	121200000831000-FY	39	PCB	123010022809-FY
8	Screw	121104080020-FY	* 40	LB Assy	843DM7240GLLB002-FY
9	Handspike	141290001421000-FY			
10	Spring	121035000625-FY	41	FFC	123820000486-FY
			42	PCB	123010022808-FY
11	Screw	121040000185-FY	43	*****	
12	Frame	141000002723-FY	44	Cabinet	141240001459000-FY
13	Screw	121106070011-FY	45	Guide	141260000318000-FY
14	Screw	121104070029-FY			
15	Top Cover	141000002220-FY	46	MB Assy	843DM7240GLMB002-FY
			47	*****	
16	Screw	121100070059-FY	48	*****	
17	Screw	121101050013-FY	49	Bracket	141000012561-FY
18	Screw	121104070008-FY	⚠ 50	Fuse (10 A)	144800000076-FY
19	Screw	121104070026-FY			
20	Screw	121104070007-FY	51	I/O	123830001555-FY
			52	I/O	123830001767-FY
21	Bracket	141000002731-FY	53	DVD Mechanism Module	See Contrast table (2)
22	Short Sheet	141000002864-FY	54	Screw	121104050032-FY
23	Cushion	121410000026-FY	55	Heat Silica Gel	121490000426-FY
24	Bolt	121050000003-FY			
25	Spring	121035000861-FY	56	Shield	121000004199-FY
			57	*****	
26	Dustproof	121450000126-FY	58	*****	
27	Bracket	141000031662-FY	59	*****	
28	Mat	121415000161-FY	60	Wire Harnes	123830000117-FY
29	Mat	121405000032-FY			
30	Button (EJECT)	141230301924018-FY	61	FFC	143820000228-FY
			62	SB Assy	See Contrast table (2)
31	Sponge	121405000004-FY	63	Deck	144840000102-FY
32	Button Cover	141000001855-FY	64	Shield	121000004351-FY
			65	Heatsink	141015000300-FY

(2) CONTRAST TABLE

DVH-760AV/XEUW5, DVH-765AV/XERD and DVH-765AV/XERI are constructed the same except for the following:

Mark	No.	Description	DVH-760AV/XEUW5	DVH-765AV/XERD	DVH-765AV/XERI
	53	DVD Mechanism Module	843DM7240GRSB002	843DM7240GLSB002-FY	843DM7240GMSB002-FY
	62	SB Assy	842DM7240GRSB002	842DM7240GLSB002	842DM7240GMSB002

<NOTE>

Any component parts in the Deck (CD Mechanism Unit) of this model can not be supplied.

If you need to replace any parts in the Deck replace whole of Deck.