


Pioneer

Service Manual



SPH-DA01/XZUC

ORDER NO.
CRT4721

APP RADIO

SPH-DA01 /XZUC


SPH-DA01 /XZEW5



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2011

K-ZZZ JULY 2011 Printed in Japan

3.2 PCB LOCATIONS



Unit Number : 843CE6666NMB004U-FY (UC model)

Unit Number : 843CE6666NMB004E-FY (EW model)

Unit Name : Main Unit

Unit Number : 843CE6666NTFT004U-FY (UC model)

Unit Number : 843CE6666NTFT004E-FY (EW model)

Unit Name : TFT Unit

Unit Number : 842CE6666NKB003-FY

Unit Name : Key Unit

Unit Number : 842CE6666NSD002-FY

Unit Name : Micro SD Unit

3.3 CLEANING



Before shipping out the product, be sure to clean the following portions by using the prescribed cleaning tools:

Portions to be cleaned	Cleaning tools
Fans	Cleaning paper : GED-008