


Pioneer

Service Manual



DVH-750AV/XEUW5

ORDER NO.
CRT5222

DVD AV RECEIVER

DVH-750AV

 /XEUW5

DVH-755AV

 /XERD

DVH-755AV

 /XERI

DVH-7580AV

 /XFBR

PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2012

K-ZZZ DEC. 2012 Printed in Japan

(1) PACKING SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Detach Panel (Ass'y)	See Contrast table (2)	15	Pulp Foam	127015000106-FY
2	Polyethylene Bag	127060000020-FY	16	Cord Ass'y	See Contrast table (2)
3	Panel	883DM7236GBFJ000-FY	17	Rim	141270000712000-FY
4	Sponge	121405000149-FY	18	Brown	127025020001-FY
5	Card Remote Control Unit	See Contrast table (2)	19	Unit Box	See Contrast table (2)
6	Polyethylene Bag	127060000019-FY	20	Contain Box	See Contrast table (2)
7	Side Key	121090000327-FY	21	Cord Ass'y	See Contrast table (2)
8	Bolt	121050000003-FY	22-1	Owner's Manual	See Contrast table (2)
9	Cushion	121410000026-FY	* 22-2	Warranty Card	See Contrast table (2)
10	Screw (M5 x 6)	121100070063-FY	* 22-3	Warning Card	See Contrast table (2)
11	Polyethylene Bag	See Contrast table (2)	22-4	Owner's Manual (English)	See Contrast table (2)
12	Polyethylene Bag	127060000023-FY	* 22-5	Service Network	See Contrast table (2)
13	Pulp Foam	127015000103-FY			
* 14	Polyethylene Bag	See Contrast table (2)			

(2) CONTRAST TABLE

DVH-750AV/XEUW5, DVH-755AV/XERD, DVH-755AV/XERI and DVH-7580AV/XFBR are constructed the same except for the following:

Mark	No.	Description	DVH-750AV/XEUW5	DVH-755AV/XERD	DVH-755AV/XERI	DVH-7580AV/XFBR
	1	Detach Panel (Ass'y)	843DM7236GLKB012-FY	843DM7236GLKB002-FY	843DM7236GLKB002-FY	CXE6185
	5	Card Remote Control Unit	CXE5124	CXE5124	CXE5124	CXE5125
	11	Polyethylene Bag	127060000021-FY	127060000021-FY	127060000021-FY	Not used
	14	Polyethylene Bag	127060020025-FY	127060020025-FY	127060020025-FY	127060020025-FY
	16	Cord Ass'y	883DM7236GBULW000-FY	Not used	Not used	883DM7236GBULW000-FY
	19	Unit Box	127020002703-FY	127020002705-FY	127020002706-FY	127020002704-FY
	20	Contain Box	127000002722-FY	127000002724-FY	127000002725-FY	127000002382-FY
	21	Cord Ass'y	Not used	843DM7236GLULW000-FY	843DM7236GLULW000-FY	Not used
	22-1	Owner's Manual	127075004208-FY	127075004205-FY	127075004206-FY	127075004204-FY
	22-2	Warranty Card	127070008002-FY	Not used	Not used	Not used
	22-3	Warning Card	127071000236-FY	127071000236-FY	127071000236-FY	CRN1124
	22-4	Owner's Manual (English)	Not used	127075004207-FY	127075004207-FY	Not used
	22-5	Service Network	Not used	Not used	Not used	CRY1227

Owner's Manual

Part No.	Language
127075004208-FY	Russian
127075004205-FY	Spanish(Espanol), Portuguese(B)
127075004207-FY	English
127075004206-FY	Arabic, Persian
127075004204-FY	Portuguese(B)

1 ■ 2 ■ 3 ■ 4 ■

NOTES : • Parts marked by " * " are generally unavailable because they are not in our Master Spare Parts List.

- The mark found on some component parts indicates the importance of the safety factor of the part.

Therefore, when replacing, be sure to use parts of identical designation.

- Screw adjacent to ∇ mark on the product are used for disassembly.

- For the applying amount of lubricants or glue, follow the instructions in this manual.

(In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING

