


Pioneer

Service Manual



DVH-750AV/XEUW5

ORDER NO.
CRT5222

DVD AV RECEIVER

DVH-750AV

 /XEUW5

DVH-755AV

 /XERD

DVH-755AV

 /XERI

DVH-7580AV

 /XFBR

PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2012

K-ZZZ DEC. 2012 Printed in Japan

(1) EXTERIOR(2)(UW5,RD,RI) SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Screw	121040000054-FY	32	Button Cover	141000001855-FY
2	Shaft	121030000336-FY	33	Mat	121405000040-FY
3	Locker	121200000837000-FY	34	Rim	141270000712000-FY
4	Washer	121440000031-FY	35	Nut	121050000023-FY
5	Gear	141200010082-FY			
6	Bracket	141000011868-FY	36	Sponge	121405000004-FY
7	Damper	121200000831000-FY	37	CB Ass'y	843DM7236GLCB002-FY
8	Screw	121104080020-FY	38	FFC	143820000257-FY
9	Handspike	141290001421000-FY	39	LB Ass'y	843DM7236GLLB002-FY
10	Spring	121035000625-FY	40	FFC	123820000486-FY
11	Screw	121040000185-FY	41	ZJ MI Ass'y	883DM7236GBZJ000-FY
12	Frame	141000002723-FY	42	Cabinet	141240001459000-FY
13	Screw	121106070011-FY	43	Guide	141260000318000-FY
14	Screw	121104070029-FY	44	MB Ass'y	See Contrast table (2)
15	Top Cover	883DM7236GBTC000-FY	45	Bracket	141000012561-FY
16	Screw	121100070059-FY	⚠ 46	Fuse (10 A)	144800000076-FY
17	Screw	121101050013-FY	47	I/O	123830001563-FY
18	Screw	121104070008-FY	48	I/O	123830001564-FY
19	Screw	121104070026-FY	49	DVD Mechanism Module	See Contrast table (2)
20	Screw	121104070007-FY	50	Screw	121104050032-FY
21	Bracket	141000002731-FY	51	Heat Silica Gel	121490000426-FY
22	Short Sheet	141000002864-FY	* 52	Shield	141000002742-FY
23	Cushion	121410000026-FY	53	Mat	121410000025-FY
24	Bolt	121050000003-FY	54	Dustproof Cover	121290020962000-FY
25	Spring	121035000861-FY	55	Screw	121045000198-FY
26	Dustproof	121450000126-FY	56	SB Ass'y	See Contrast table (2)
27	Bracket	141000031662-FY	57	Wire Harnes	123830000117-FY
28	Mat	121415000161-FY	58	FFC	143820000228-FY
29	Mat	121405000032-FY	59	Deck	144840020083-FY
30	Button (EJECT)	141230301924018-FY	60	Heatsink	141015000300-FY
31	Heat Silica Gel	121490000464-FY	61	Lever	121290222257-FY
			62	Sheet	121490000117-FY

(2) CONTRAST TABLE


DVH-750AV/XEUW5, DVH-755AV/XERD and DVH-755AV/XERI are constructed the same except for the following:

Mark	No.	Description	DVH-750AV/XEUW5	DVH-755AV/XERD	DVH-755AV/XERI
	44	MB Ass'y	843DM7236GRMB012-FY	843DM7236GLMB002-FY	843DM7236GMMB002-FY
	49	DVD Mechanism Module	843DM7236GRSB001-FY	843DM7236GLSB001-FY	843DM7236GMSB001-FY
	56	SB Ass'y	842DM7236GRSB001-FY	842DM7236GLSB001-FY	842DM7236GMSB001-FY

<NOTE>

Any component parts in the Deck (CD Mechanism Unit) of this model can not be supplied.
If you need to replace any parts in the Deck replace whole of Deck.

9.3 EXTERIOR(2)(UW5,RD,RI)



DVH-750AV/XEUW5