


Pioneer

Service Manual



DVH-760AV/XEUW5

ORDER NO.
CRT5426

DVD AV RECEIVER

DVH-760AV /XEUW5

DVH-765AV /XERD

DVH-765AV /XERI

DVH-7680AV /XFBR



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2013

K-ZZZ OCT. 2013 Printed in Japan

(1) PACKING (XEUW5, XERD, XERI) SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Detach Panel (Assy)	See Contrast table (2)	16	Cord Assy	See Contrast table (2)
2	Polyethylene Bag	127060000020-FY	17	Rim	141270000712000-FY
3	Panel Box	141250000116198-FY	18	Brown	127025020001-FY
4	Sponge	121405000149-FY	19	Unit Box	See Contrast table (2)
5	Card Remote Control Unit	CXE5124	20	*****	
6	Polyethylene Bag	1270600000019-FY	21-1	Owner's Manual	See Contrast table (2)
7	Side Key	121090010327-FY	21-2	Owner's Manual	See Contrast table (2)
8	Bolt	121050000003-FY	21-3	Owner's Manual	See Contrast table (2)
9	Cushion	121410000026-FY	21-4	Owner's Manual	See Contrast table (2)
10	Screw (M5 x 6)	121100070063-FY	* 21-5	Warranty Card	See Contrast table (2)
11	Polyethylene Bag	1270600000021-FY			
12	Polyethylene Bag	1270600000023-FY	* 21-6	Warning Card	127071000236-FY
13	Pulp Foam	127015000103-FY	21-7	Warning Label	12707000800-FY
14	Polyethylene Bag	127060020025-FY			
15	Pulp Foam	127015000106-FY			

(2) CONTRAST TABLE

DVH-760AV/XEUW5, DVH-765AV/XERD and DVH-765AV/XERI are constructed the same except for the following:

Mark	No.	Description	DVH-760AV/XEUW5	DVH-765AV/XERD	DVH-765AV/XERI
	1	Detach Panel (Assy)	843DM7240GRKB002-FY	843DM7240GLKB002-FY	843DM7240GLKB002-FY
	16	Cord Assy	843DM7240GRPWR004-FY	843DM7240GLPWR004-FY	843DM7240GLPWR004-FY
	19	Unit Box	127020003915-FY	127020003917-FY	127020003918-FY
	21-1	Owner's Manual	127075015154-FY	Not used	Not used
	21-2	Owner's Manual	Not used	127075005151-FY	127075005151-FY
	21-3	Owner's Manual	Not used	127075005152-FY	Not used
	21-4	Owner's Manual	Not used	Not used	127075005153-FY
*	21-5	Warranty Card	127070008002-FY	Not used	Not used

Owner's Manual

Part No.	Language
127075015154	Russian
127075005152	Spanish(Espanol), Portuguese(B)
127075005151	English
127075005153	Arabic, Persian


9. EXPLODED VIEWS AND PARTS LIST

NOTES : • Parts marked by " * " are generally unavailable because they are not in our Master Spare Parts List.

- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Screw adjacent to ∇ mark on the product are used for disassembly.
- For the applying amount of lubricants or glue, follow the instructions in this manual.

(In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING (XEUV5, XERD, XERI)



DVH-760AV/XEUV5