


Pioneer

Service Manual



DVH-860AV/XEUW5

ORDER NO.
CRT5452

DVD AV RECEIVER

DVH-860AV /XEUW5

DVH-865AVBT /XERD

DVH-865AVBT /XERI

DVH-8680AVBT /XFBR



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2013

K-ZZZ DEC. 2013 Printed in Japan

(1) PACKING SECTION PARTS LIST

Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Card Remote Control Unit	See Contrast table (2)			
2	Detach Assy	See Contrast table (2)	*	12-5 Service Network	See Contrast table (2)
3	Pulp Form	127015000249	12-6	Label	See Contrast table (2)
4	Pulp Form	127015000250	12-7	Label	See Contrast table (2)
5	Unit Box	See Contrast table (2)	13	Cord Assy	See Contrast table (2)
			14	Case Assy	See Contrast table (2)
6	Contain Box	See Contrast table (2)			
7	Polyethylene Bag	127060000019	15	Sponge	121405000149
8	Polyethylene Bag	127060000020	16	Panel	141250000116198
9	Polyethylene Bag	127060000021	17	Side Key	121090010327
10	Polyethylene Bag	127060000023	18	Screw (M5 x 6)	121100070063
			19	Brown	127025020001
11	Polyethylene Bag	127060020025			
* 12-1	Warranty Card	See Contrast table (2)	20	Rim	141270000509000
* 12-2	Warning Card	See Contrast table (2)	21	Bolt	121050000003
12-3	Owner's Manual	See Contrast table (2)	22	Cushion	121410000026
12-4	Owner's Manual	See Contrast table (2)	23	Microphone	See Contrast table (2)

(2) CONTRAST TABLE

DVH-860AV/XEUW5, DVH-865AVBT/XERD, DVH-865AVBT/XERI and DVH-8680AVBT/XFBR are constructed the same except for the following:

Mark	No.	Description	DVH-860AV /XEUW5	DVH-865AVBT /XERD	DVH-865AVBT /XERI	DVH-8680AVBT /XFBR
	1	Card Remote Control Unit	CXE5124	CXE5124	CXE5124	CXE5125
	2	Detach Assy	843DM7387ARKB003	843DM7387BLKB003	843DM7387BLKB003	CXE7342
	5	Unit Box	127020003914	127020003920	127020003916	127020004008
	6	Contain Box	Not used	Not used	Not used	127000002382
*	12-1	Warranty Card	127070008002	Not used	Not used	Not used
*	12-2	Warning Card	127071000236	127071000236	127071000236	CRN1124
	12-3	Owner's Manual	127075005211	127075005208	127075005208	127075005206
	12-4	Owner's Manual	Not used	127075005209	127075005210	Not used
*	12-5	Service Network	Not used	Not used	Not used	CRY1227
	12-6	Label	127070008000	127070008000	127070008000	127070005707
	12-7	Label	Not used	Not used	Not used	127071004303
	13	Cord Assy	883DM7236GBULW000-FY	842DM7236GLMB002	842DM7236GLMB002	883DM7387BBPWR004
	14	Case Assy	*883DM7236GBFJ000	*883DM7236GBFJ000	*883DM7236GBFJ000	883DM7387BBFA010
	23	Microphone	Not used	123650000003	123650000003	123650000003

Owner's Manual, Installation Manual

Part No.	Language
127075005211	Russian
127075005208	English
127075005209	Spanish(Espanol), Portuguese(B)
127075005210	Arabic, Persian
127075005206	Portuguese(B)

9. EXPLODED VIEWS AND PARTS LIST

NOTES : • Parts marked by " * " are generally unavailable because they are not in our Master Spare Parts List.

• The Δ mark found on some component parts indicates the importance of the safety factor of the part.

Therefore, when replacing, be sure to use parts of identical designation.

• Screw adjacent to ∇ mark on the product are used for disassembly.

• For the applying amount of lubricants or glue, follow the instructions in this manual.

(In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING

