


Pioneer

Service Manual



AVH-3500DVD/XEUC

ORDER NO.
CRT5348

DVD AV RECEIVER

AVH-3500DVD /XEUC

AVH-3550DVD /XERD

AVH-3550DVD /XERC

AVH-3550DVD /XERI

AVH-3500DVD /XEUW5



PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2013

K-ZZZ JUNE 2013 Printed in Japan

	5		6		7		8	
EXTERIOR (2) SECTION PARTS LIST								
Mark No.	Description		Part No.					
1	Holder		121000003712					
2	Holder		121000003713				A	
3	Screw		121045000007					
4	Screw		121045000040					
5	Screw		121100070098					
6	Screw		121104050023					
7	Screw		121106070011					
8	Gasket		121405000311					
9	Spacer		121410000510					
10	Sheet		121455010113					
11	FPC		123020010136				B	
12	Grille		141210101672028					
13	Cover		141210101676028					
14	Touch Panel		143420000079					
15	TFT LCD		143420020069					
16	DVD Mechanism Module		843DV7791GASB004					
17	TFT PCB Assy		843DV7791GATFT004					
18	Insulator		121415000227					
19	FFC		143820000240					
							C	
							D	
							E	
							F	

■ 1 ■ 2 ■ 3 ■ 4 ■



B

C

D

E

F