


Pioneer

Service Manual



AVH-3500DVD/XEUC

ORDER NO.
CRT5348

DVD AV RECEIVER

AVH-3500DVD /XEUC**AVH-3550DVD** /XERD**AVH-3550DVD** /XERC**AVH-3550DVD** /XERI**AVH-3500DVD** /XEUW5

PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2013

K-ZZZ JUNE 2013 Printed in Japan

EXTERIOR (3) SECTION PARTS LIST

Mark No.	Description	Part No.	
1	Cover	121000003716	
2	Holder	121000013717	
3	Screw	121100000067	A
4	Screw	121100050080	
5	Screw	121100070098	
6	Screw	121100070131	
7	Sheet	121410000437	
8	Insulator	121415000229	
9	Sheet	121490000333	
10	Sheet	121490000461	
11	Sheet	121490000705	B
12	Cord Assy	123830001606	
13	Fan Motor	124850000019	
14	Cover	141000000962	
15	Cover	141005000117	
16	Heat Sink	141015000362	
17	Mother PCB Assy		
	3500DVD/XEUC	843DV7791GNMB004	
	3500DVD/XEUW5	843DV7791GRMB004	
	3550DVD/XERC	843DV7791GAMB004	C
	3550DVD/XERD	843DV7791GLMB004	
	3550DVD/XERI	843DV7791GMMB004	
18	Sheet	121410000517	
19	Antenna Cable	123835001138	
⚠ 20	Fuse (10 A)	124800000106	
21	TUNER UNIT	843DV7791GATN006	

A

B

C

D

E

F

9.4 EXTERIOR (3)

A

B

C

D

E

F

