


Pioneer

Service Manual



X-SMC1-K

ORDER NO.
RRV4270

Slim AV Micro System

X-SMC1-K

X-SMC1-S

X-SMC1-W

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Region No.	Serial No.	Remarks
X-SMC1-K	CUXZTSM	AC 100 V to 240 V	1	&&&&#####UC	UC : U.S., Canada
X-SMC1-K	SYXZT8	AC 100 V to 240 V	2	&&&&#####YY	YY : Europe
X-SMC1-S	SYXZT8	AC 100 V to 240 V	2	&&&&#####YY	YY : Europe
X-SMC1-S	FLXZT	AC 100 V to 240 V	3	&&&&#####LS	LS : Asia
X-SMC1-S	AXZT5	AC 100 V to 240 V	6	&&&&#####CN	CN : China
X-SMC1-W	AXZT5	AC 100 V to 240 V	6	&&&&#####CN	CN : China




PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan
PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
©PIONEER CORPORATION 2011

K-IZV NOV. 2011 Printed in Japan

(2) CONTRAST TABLE

X-SMC1-K/CUXZTSM, SYXZT8, X-SMC1-S/SYXZT8, FLXZT, AXZT5 and X-SMC1-W/AXZT5 are constructed the same except for the following:

Mark	No.	Symbol and Description	X-SMC1-K/ CUXZTSM	X-SMC1-K/ SYXZT8	X-SMC1-S/ SYXZT8	X-SMC1-S/ FLXZT	X-SMC1-S/ AXZT5	X-SMC1-W/ AXZT5	A
	1	DISPLAY PCB Assy	A2P302ADP0	A2P306ADP0	A2P301ADP0	A2P304ADP0	A2P307ADP0	A2P303ADP0	
	2	DOCK PCB Assy	A2P302AFF0	A2P306AFF0	A2P301AFF0	A2P304AFF0	A2P307AFF0	A2P303AFF0	
	3	BLUETOOTH PCB Assy	A2P302AFG0	A2P306AFG0	A2P301AFG0	A2P304AFG0	A2P307AFG0	A2P303AFG0	
	4	MAIN PCB Assy	A2P302AF40	A2P306AF40	A2P301AF40	A2P304AF40	A2P307AF40	A2P303AF40	
	5	OPERATION PCB Assy	A2P302A270	A2P306A270	A2P301A270	A2P304A270	A2P307A270	A2P303A270	
	6	TUNER PCB Assy	A2P302A290	A2P306A290	A2P301A290	A2P304A290	A2P307A290	A2P303A290	
	7	DVD MT PCB Assy	A2P302A130	A2P306A130	A2P301A130	A2P304A130	A2P307A130	A2P303A130	
	23	Front Cabi Assy	7A701B393A	7A701B393A	7A701B393A	7A701B393A	7A701B393A	7A701B404A	
	27	Front Panel Assy	7A701B414A	7A701B414A	7A701B407A	7A701B407A	7A701B407A	7A701B423A	
	28	Front Panel	701WPJD897	701WPJD897	701WPJD892	701WPJD892	701WPJD892	701WPJD912	B
	30	Rear Cabi Assy	7A702B484A	7A702B484A	7A702B484A	7A702B484A	7A702B484A	7A702B483A	
	31	Cover BT Adapter	702WPB0140	702WPB0140	702WPB0140	702WPB0140	702WPB0140	702WPBA296	
	32	Top Panel	711WPD0808	711WPD0808	711WPD0808	711WPD0808	711WPD0808	711WPD0808	
	34	Cover Dock Top Assy	7A7020398A	7A7020398A	7A7020398A	7A7020398A	7A7020398A	7A702B501A	
	36	Grille Frame L Assy	7A7140001A	7A7140001A	7A7140001A	7A7140001A	7A7140001A	7A714A001A	
	37	Grille Frame R Assy	7A7140002A	7A7140002A	7A7140002A	7A7140002A	7A7140002A	7A714A002A	
	38	Button Frame Assy	7A735A064A	7A735A064A	7A735A064A	7A735A064A	7A735A064A	7A735A066A	
	39	Button Frame	735WPJA873	735WPJA873	735WPJA873	735WPJA873	735WPJA873	735WPJA875	
	52	Tray	701WPJ1586	701WPJ1586	701WPJ1586	701WPJ1586	701WPJ1586	701WPJD900	
	54	Bottom Case	702WPJ0072	702WPJ0072	702WPJ0072	702WPJ0072	702WPJ0072	702WPJA033	C
	57	Hook	761WPAA317	761WPAA317	761WPAA317	761WPAA317	761WPAA317	761WPAA316	
	67	Caution	J2P30129A	J2P30129A	J2P30129A	J2P30129A	J2P30329A	J2P30329A	
	68	Sheet AC Label	Not used	Not used	Not used	Not used	723000F400	723000F392	
	71	Screw	810213060S	810213060S	810213060S	810213060S	810213060S	810223060U	



X-SMC1-K