

Pioneer Dj

Service Manual



PLX-500-K

ORDER NO.
RRV4664

TURNTABLE

PLX-500-K PLX-500-W

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Remarks
PLX-500-K, -W	LPWSYXEG	AC 110 V to 120 V or 220 V to 240 V	
PLX-500-K, -W	FWUXEGCB	AC 110 V to 120 V or 220 V to 240 V	

THIS SERVICE MANUAL SHOULD BE USED TOGETHER WITH THE FOLLOWING MANUAL(S).

Model	Order No.	Remarks
PLX-500-K, -W	RRV4665	SCHEMATIC DIAGRAM, PCB CONNECTION DIAGRAM, PCB PARTS LIST



Pioneer DJ Corporation

6F, Yokohama I-Mark Place, 4-4-5 Minatomirai, Nishi-ku, Yokohama, Kanagawa 220-0012 JAPAN

© 2016 Pioneer DJ Corporation

K-ZZZ SEPT. 2016

9. EXPLODED VIEWS AND PARTS LIST

NOTES: ● Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

● The Δ mark found on some component parts indicates the importance of the safety factor of the part.

Therefore, when replacing, be sure to use parts of identical designation.

● Screws adjacent to ∇ mark on product are used for disassembly.

● For the applying amount of lubricants or glue, follow the instructions in this manual.

(In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING SECTION

