Pioneer

# Service Manual



VSX-1131

ORDER NO.
**ARP4006**

AV RECEIVER

# VSX-1131

# VSX-LX301

**THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).**

| Model | Type | Power Requirement | Remarks |
|---|---|---|---|
| VSX-1131(B) | MDC | AC 120V | |
| VSX-1131(B) | MMP | AC 220V to 240V | |
| VSX-1131(S) | MMP | AC 220V to 240V | |
| VSX-1131(B) | MMB | AC 220V to 240V | |
| VSX-1131(B) | MMA | AC 220V to 240V | |
| VSX-1131(B) | MDF | AC 120V | |
| VSX-LX301(B) | MDC | AC 120V | |

© Onkyo & Pioneer Corporation 2016

O-4561

Pioneer

# Service Manual



VSX-1131

ORDER NO.
**ARP4006**

AV RECEIVER

# VSX-1131

# VSX-LX301

**THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).**

| Model | Type | Power Requirement | Remarks |
|---|---|---|---|
| VSX-1131(B) | MDC | AC 120V | |
| VSX-1131(B) | MMP | AC 220V to 240V | |
| VSX-1131(S) | MMP | AC 220V to 240V | |
| VSX-1131(B) | MMB | AC 220V to 240V | |
| VSX-1131(B) | MMA | AC 220V to 240V | |
| VSX-1131(B) | MDF | AC 120V | |
| VSX-LX301(B) | MDC | AC 120V | |

© Onkyo & Pioneer Corporation 2016

O-4561

# Rear section (VSX-LX301)

## Exploded View




VSX-LX301

# Rear section (VSX-LX301)

## Exploded View




VSX-LX301